

PARTS LIST

GASOLINE CHAINSAW

PC3530

Art# 030652




Use only NAKAYAMA genuine parts as specified in the parts list for repair or replacement.
Check if your machine meets the applicable models listed below.
The contents described in the parts list may change due to improvement.



APPLICABLE:

June 2020

PC3530 Fig.1



No#	Code	Description (EN)	QTY	Notes	No#	Code	Description (EN)	QTY	Notes
1	0306520001	NUT M8x1	1		56	0306520056	SCREW ST4.2x11	2	
2	0306520002	FLYWHEEL-ASSY	1		57	0306520057	BREATH NIPPLE	1	
3	0306520003	WOODRUFF KEY3x10	1		58	0306520058	FILTER VENT	1	
4	0306520004	SMALL SEAL OIL 12x22x5	1		59	0306520059	SPRING-BREATH NIPPLE	1	
5	0306520005	6001 BEARING-BALL	2		60	0306520060	POTHOOK	1	
6	0306520006	BIG SEAL OIL 12x28x6	1		61	0306520061	PLUG-PAD	3	
7	0306520007	SCREW M5x20	4		62	0306520062	PAD-RUBBER	3	
8	0306520008	SUPPORT-CRANKCASE BEARING	1		63	0306520063	NUT M5	4	
ZC1	0306520ZC1	CRANK SHAFT AND PISTON ASSY	1		64	0306520064	SCREW M5x45	1	
9	0306520009	CRANK SHAFT ASSY	1		65	0306520065	WASHER	2	
10	0306520010	NEEDLE BEARING SNAP	2		66	0306520066	COVER CAP	1	
11	0306520011	NEEDLE BEARING	1		67	0306520067	TRIGGER PIN 5x26	1	
12	0306520012	PISTON	1		68	0306520068	HANDLE	1	
13	0306520013	RING-SNAP	2		69	0306520069	SCREW M5x16	1	
14	0306520014	PISTON-PIN	1		70	0306520070	PIPE-CARBURATOR	2	
15	0306520015	PISTON-RING	1		71	0306520071	SWITCH STOP	1	
16	0306520016	CYLINDER	1		72	0306520072	SPRING-TRIGGER	1	
17	0306520017	SPARK PLUG	1		73	0306520073	TRIGGER	1	
18	0306520018	WIRE-STOP	1		74	0306520074	LEVER-TRIGGER	1	
19	0306520019	SCREW M4x20	2		75	0306520075	GROMMET-CHOKE KNOB	1	
20	0306520020	ELECTRON IGNITION ASSY	1		76	0306520076	CHOKE KNOB	1	
21	0306520021	ELECTRON IGNITION PLATE	2		77	0306520077	ROD THROTTLE	1	
22	0306520022	BOOT INTAKE	1		78	0306520078	COVER-REAR HANDLE	1	
23	0306520023	SCREW M4x14	4		79	0306520079	SCRW ST4.2x16	7	
24	0306520024	WASHER MUFFLER	1		80	0306520080	CHINESE CARBURATOR ASSY	1	
25	0306520025	MUFFLER ASSY	1		81	0306520081	SUPPORT-AIR FILTER	1	
26	0306520026	COVER-MUFFLER	1		82	0306520082	COVER-AIR FILTER	1	
27	0306520027	SCREW M5x40	2		83	0306520083	SCREW M5x45	2	
28	0306520028	SCREW ST4.2x13	7		84	0306520084	SPONGE-AIR FILTER	1	
29	0306520029	COVER-TOP	1		85	0306520085	COVER-AIR FILTER SPONGE	1	
30	0306520030	PAPER GASKET	1		86	0306520086	COVER-AIR FILTER	1	
31	0306520031	WIRE-GROUND	1		87	0306520087	KNOB-AIR FILTER	1	
32	0306520032	SCREW M5x16	5		ZC6	0306520ZC6	CLUTCH ASSY	1	
33	0306520033	HOSE ADAPTER	2		88	0306520088	SPRING-CLUTCH	2	
34	0306520034	OIL RETURN PIPE	1		89	0306520089	CLUTCH SUPPORT	2	
ZC2	0306520ZC2	FUEL FILTER ASSY	1		90	0306520090	CLUTCH RETAINER	1	
35	0306520035	FUEL HOSE	1		91	0306520091	WASHER-CLUTCH	1	
36	0306520036	SUPPORT-FUEL HOSE	1		92	0306520092	DRUM-CLUTCH	1	
37	0306520037	CONNECT PIPE CLIP	1		93	0306520093	BEARING-NEEDLE CLUTCH	1	
38	0306520038	FUEL FILTER	1		94	0306520094	WORM	1	
ZC3	0306520ZC3	BALANCE ASSY	1		95	0306520095	WASHER-OIL PUMP	1	
39	0306520039	COVER-BALANCE	1		96	0306520096	COVER-OIL PUMP	1	
40	0306520040	BALANCE	1		97	0306520097	WASHER-SPRING	2	
41	0306520041	COVER-BALANCE	1		98	0306520098	WASHER	3	
42	0306520042	CONNECT BALANCE	1		99	0306520099	OIL PUMP ASSY	1	
43	0306520043	PIN	1		100	0306520100	FUEL INJECTION NOZZLE	1	
44	0306520044	WASHER	4		101	0306520101	OIL INLET HOSE	1	
45	0306520045	FUEL TANK	1		102	0306520102	OIL FILTER	1	
46	0306520046	OIL VACULOT	1		103	0306520103	SPONGE-DUSTPROOF	1	
ZC4	0306520ZC4	FUEL CAP ASSY	1		104	0306520104	SUPPORT-INTAKE AIR	1	
47	0306520047	FUEL CAP	1		105	0306520105	SCREW ST4.2x8.5	7	
48	0306520048	WASHER-FUEL CAP	1		106	0306520106	BAFFLE-FAN	1	
49	0306520049	HOLDING-OIL CAP	1		ZC7	0306520ZC7	PULLEY-STARTER ASSY	1	
ZC5	0306520ZC5	OIL CAP ASSY	1		107	0306520107	SCREW ST4.8x16	1	
49	0306520049	HOLDING-OIL CAP	1		108	0306520108	WASHER φ5x15x1.5	1	
50	0306520050	WASHER-OIL CAP	1		109	0306520109	PULLEY STARTER	1	
51	0306520051	OIL CAP	1		110	0306520110	COVER-SPRING	1	
52	0306520052	CHAIN CATCHER	1		111	0306520111	SPRING-STARTER	1	
53	0306520053	SCREW	1		112	0306520112	HOUSING-STARTER	1	
54	0306520054	SPONGE -PLATE BAR	1		113	0306520113	ROPE JACKET	1	
55	0306520055	PLATE-BAR	1		114	0306520114	WASHER-STARTER HANDLE	1	

PC3530 Fig.1

No#	Code	Description (EN)	QTY	Notes
115	0306520115	WASHER	2	
116	0306520116	SPRING-KICK BACK	1	
117	0306520117	STARTER HANDLE	1	
118	0306520118	ROPE-STARTER	1	
119	0306520119	PAD RUBBER SUPPORT	1	
120	0306520120	SCREW ST3.5×10	1	
121	0306520121	HANDLE ASST	1	
122	0306520122	SCREW ST4.8×16	4	
ZC8	0306520ZC8	BRAKE ASSY	1	
123	0306520123	COVER HEAD	1	
124	0306520124	LEVERAGE-BRAKE	1	
125	0306520125	SPRING-LEVERAGE	1	
126	0306520126	WASHER-SPRING	1	
127	0306520127	SPRING-BRAKE	1	
128	0306520128	SCREW M5×30	1	
129	0306520129	BUSHING	1	
130	0306520130	PIN-LEVERAGE	1	
131	0306520131	SUPPORT SPRING BRAKE	1	
132	0306520132	SPRING-LEVERAGE	1	
133	0306520133	PIN-CHAINADJUSTING	1	
134	0306520134	SPROCKET-CHAINADJUSTING	1	
135	0306520135	SCREW CHAINADJUSTING	1	
136	0306520136	HOUSING BRAKE	1	
137	0306520137	COVER CHAIN ADJUSTING	1	
138	0306520138	COVER SPRING BRAKE	1	
ZC9	0306520ZC9	MAIN AND AUXILIARY LEVER ASSY	1	
139	0306520139	MAIN LEVER	1	
140	0306520140	SHORT PIN	2	
141	0306520141	LONG PIN	1	
142	0306520142	AUXILIARY LEVER	1	
143	0306520143	PLATE-BRAKE	1	
144	0306520144	SPRING-BRAKE	1	
145	0306520145	BAND BRAKE	1	
146	0306520146	PIN	1	
147	0306520147	NUT-BAR	2	
148	0306520148	HOUSING-MUFFLER	1	
149	0306520149	SPIKE	1	
150	0306520150	SCREW ST4.8×14	2	
151	0306520151	GUIDE BAR	1	
152	0306520152	CHAIN	1	
153	0306520153	BAR PROTECTOR	1	
Z10	0306520Z10	CYLINDER-PISTON ASSY	1	
Z11	0306520Z11	SHORT BLOCK ASSY	1	
Z12	0306520Z12	CHAIN TENSIONER ASSY	1	